




Installation Guide

FLOC 3D ACOUSTIC TILE

DIRECT FIX

YOU WILL NEED



FOCUS CLIPS (Required number will equal the amount of tiles)




SCREWS



500X500 FOCUS 3D TILE

step 1



step 1

Floc 3D Acoustic Tiles are 500x500. Measure your ceiling or wall space and work out where you would like your tiles mounted as an area divisible by 500mm.

In most situations it is best to measure out from a wall. Mark a straight line. This is your **datum**. On the datum mark your **first corner**.

step 2

For every junction of 4 tiles designate a focus clip.
For all edges break one Focus clip in half.
For the four corners break one Focus clip into quarters.

step 3

Using fixings suitable for your substrate, fix the first corner in place (always use a mechanical means of fixing).

step 4

Work your way along the ceiling or wall, using a guide to ensure accuracy. Set out the clips at 500mm centers (never use the tiles to measure spacing).

step 5

Once you have reached the desired length, use another quarter clip. Start a new row and check the distance is consistently at 500mm centers in both directions.


step 6

Once you have two rows of clips, double check your spacing by installing the first row of tiles. Always stay one row ahead of the installed tiles so the tiles don't interfere with the spacing.

step 7

Install the rest of your clips and put up the tiles to finish.

step 2




4 Tile Junctions


Edges

Corners

step 3



step 4



step 5-7

